VERSABUILT

| | | | MONTH DATE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------|---------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|---|---|---|---|---|---|---|---|---|----|-------|----------------------------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|------|----|
| VB | VBX-160 PREVENTATIVE MAINTENANCE LIST | | MONTH | | | | | | | | | | | 23 | 23 24 25 26 27 28 29 30 31 | | | | | | | | | | | | | | | | | | |
| Eres | P.M. Activity | Instruction | Responsibility | 1 | 2 | 3 | 4 | 5 | 6 | / | 8 | 9 | 10 | 11 12 | 13 | 14 | 15 | 16 | 1/ | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 : | 31 |
| | | Remove any and all Chips/Debris | maponatomy | - | | | | | - | - | - | - | - | - | - | - | - | - | | | | | | - | - | - | - | - | - | - | | | - |
| | | Inspect CNC for excessive chip build up that could block the door | | | | | | | | | | _ | | - | | | | | | | | | | | | | | | | - | | | _ |
| | | Empty, rinse, and refil to cover the pump by 3 inches | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | _ |
| | | Wipe off coolant residue from Robot, gripper fingers, and enclosure | | | | | | | | | | | | | | | | | | | | | | | | | | | | | _ | | _ |
| W | Wipe Down Robot Cell | Wipe Down Sheet Metal and Doors, Inside and Out | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| W | | Wipe down with damp cloth | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| м | Check controller and computer area to verify liquid is not entering the box. | Seal enclosure if needed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| м | | Adjust and tighten as necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| м | | Empty dip bucket, remove filter from pump and replace with new filter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| м | Inspect Hobot Cabeing | Visually inspect the control cabling between the robot and the robot control cabinet (IRC5) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| м | | Inspect for worn cables or hoses. Ensure there are no pinched air hoses. Make sure zip ties aren't too tight. This may cause a sensor to pull loose. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| M | Clean gripper | Clean to ensure there is no build up of coolant, corrosion or chips. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Grease vise zerk fittings | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Inspect for worn or irregular wear on soft jaws | | | | | | | | _ | | | | | | | | | | | | | | | | | | | | | | | |
| | | Verify there is no excessive play in the hinge posts when latched | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| M | | Clean the moist dust filter on the back of the IRC5 cabinet | | | | | | | | | | T | T | | | | | | | | | | | | | | | | | | | | |
| м | | Verify that Gripper, Door and Vise sensors are snug and activate at correct positions | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

WWW VERSABUILT COM

D10077 REV A JUNE 2018

D10077 REV A JUNE 2018

| | В | C | D | E | F | G | Н | Į I | J |
|------------------|----------------|-------------------------------------------------|------------------------------|----------|-----------|-----------|-----------|-----------|------------------------------------------------------------|
| 1 2 3 4 | VER | SABUILT | | | | | | | |
| 5 | | Recommended A | ABB IRB12 | 00 Rol | oot Par | ts Rep | laceme | ent Sch | edule |
| 6 | Location | Description | Part # | 6 Months | 12 Months | 18 Months | 24 Months | 36 Months | Notes |
| 7 | | Gripper Sensors (pre Jan 2018) | 5001808 | | Х | | | | |
| 8 | Gripper | Gripper Harness with Sensors (post Jan 2018) | 5002142 | | | х | | | |
| 9 | | Gripper | 5001771 | | Х | | | | |
| 10 | IRC5 Cabinet | IRC5 CMOS Battery | 5003367 | | | | | Х | Reference ABB Maintenance Document 3HAC046983 |
| 11 | inteo oublinet | IRC5 Cabinet Moist Dust Filter | | | | | х | | Reference ABB Maintenance document 3HAC021313-001 3.4.2 |
| 12 | Robot Arm | Timing Belt on ABB Robot | | | | | | Х | Reference ABB Maintenance Document 3HAC046983 |
| 13 | HUDUL AIIII | Replace the ABB Battery pack | | | | | | Х | Reference ABB Maintenance Document 3HAC046983 3.4.1 |
| 14 | VBX | Pump Filter Bag | 5001210 | Х | | | | | |
| 15 | Enclosure | Wash Bucket Pump | | | | | | Х | |
| 16 | Enclosure | Gate post parts | 5000773 | | | Х | | | |
| 17 | | Rotary Coupler O-Ring | Contact Versabult | х | | | | | |
| 18 | Work Holding | Vise Sensors | M5 - 5002298 M8 - 5003040 | | Х | | | | |
| 19 | | Vise Cable "Y" | 5002506 | | Х | | | | |
| 20 | | Vise Cable 5m extension | 5002507 | | Х | | | | |
| 21 22 | WWW.VERSABUIL | T.COM | D10078 REV A JUNE | E 2018 | | | | | |